



ASSEMBLY DETAIL

ASSEMBLY INSTRUCTIONS:

STEP 1

AFTER THE FOUNDATION IS IN PLACE, ATTACH COLUMN BASE PLATES TO ANCHOR BOLTS AND LOOSELY FASTEN. MAKE SURE THAT THE PROPER CENTER DISTANCE IS SET BOTH AT THE TOP AND BOTTOM OF THE W-BEAM COLUMN. LEVELING NUTS ARE USED TO PLUM EACH COLUMN. ONCE THE COLUMN IS SET PROPERLY, TIGHTEN THE ANCHOR AND LEVELING NUTS SECURELY.

STEP 2

INSTALL THE C6x8.2 BASE CHANNEL ON TOP OF THE WELDED IN ANGLE SUPPORTS.

STEP 3

PLACE PANELS INTO THE W-BEAM SUPPORT COLUMNS. THIS SHOULD BE DONE EITHER BY SLIDING THE PANELS DOWN THE W-BEAMS FROM THE TOP OR BY RAISING ONE SIDE OF EACH PANEL TO MANEUVER THEM INTO THE W-BEAM COLUMN. THE END OF THE LSE PANELS SHOULD FIT INTO THE FLANGE OF THE W-BEAM WITH THE PANEL FLANGES OVERLAPPING THE COLUMN FLANGES. EACH PANEL SHOULD OVERLAP THE ONE BELOW AND LOCK DOWN ONTO THE BOTTOM PANEL. INSERT THE CORRECT AMOUNT OF PANELS TO REACH THE DESIRED STACK HEIGHT.

STEP 4

AFTER THE PANELS ARE POSITIONED IN PLACE IN THE W-BEAM SUPPORT COLUMNS, PLACE THE TOP CAP OR CHANNEL OVER THE TOP OF THE PANEL. THERE ARE SLOTTED HOLES IN THE TOP CAP PIECES TO ALLOW THEM TO ALIGN WITH THE STUDS WELDED AT THE TOP OF EACH W-BEAM COLUMN. THE TOP CAP SHOULD REST ON TOP OF THE PANELS AND COLUMN. PLACE A FENDER WASHER AND "PS" PUSHNUT FASTENER ON THE 3/8" DIA. ROUND BAR. DRIVE THE PUSHNUT FASTENER DOWN THE ROUND BAR TO WITHIN 1/8" OF THE FENDER WASHER. DO NOT DRIVE THE PUSHNUT FASTENER DOWN TIGHT. ALLOW CLEARANCE BETWEEN THE PUSHNUT AND TOPCAP FOR EXPANSION AND CONTRACTION.

THIS DESIGN, DRAWING AND SPECIFICATION IS THE EXCLUSIVE PROPERTY OF SOUND FIGHTER SYSTEMS, LLC. IT AND/OR THE DESIGN THEREIN ARE NOT TO BE COPIED, SOLD, TRANSFERRED OR REPRODUCED IN ANY WAY AND IS SUBJECT TO RETURN ON DEMAND. THE ITEMS DESCRIBED ARE NOT TO BE BUILT OR ASSEMBLED OR IT'S DESIGN CRITERIA DISCLOSED TO OTHER PARTIES WITHOUT THE EXPRESSED WRITTEN PERMISSION OF SOUND FIGHTER SYSTEMS, LLC.

SOUND FIGHTER SYSTEMS, LLC



P.O. Box 7216
Shreveport, Louisiana
71137-7216
TEL. 318-861-6640
FAX 318-865-7373
Website: www.soundfighter.com

DRAWN	KG	DATE	1/22/08
APPRV		DATE	

REV	DESCRIPTION	BY	DATE
	LSE NOISE BARRIER SYSTEM		
	STANDARD WALL		
	ASSEMBLY & INSTRUCTIONS		
SIZE	PROJECT	DWG NO	REV
B	.	ASSEMBLY-1.dwg	.
SCALE	N.T.S.		SHEET 1